

Operation

The e-Trap voice command system remote comes set as an 8 channel remote. To activate voice control refer to instructions.

NOTE: The TP button allocation is defaulted to buttons 1 + 2

Using remote with voice mode on single shot mode

1. Press the button you wish to activate and the 'Voice' LED will illuminate.
2. When ready, call "PULL" with a firm voice. The 'TX' LED will flash and the remote will exit voice mode.
3. To exit voice mode at any time, press the **MENU** button firmly.

NOTE: If no voice activation has been detected after 15 seconds, voice mode will deactivate.

Using remote with voice continuous mode on

1. Press the button you wish to activate and the 'Voice' LED will illuminate.
2. Continue to hold until 'DT' LED illuminates.
3. Now release button and after a 3 second delay. The 'DT' LED will turn off and the 'Voice' LED will flash indicating continuous activation mode.
4. When ready, call "PULL" with a firm voice. The 'TX' LED will flash, then the 'DT' LED will illuminate and stay on for the set dead time.
(Voice can't activate again until dead time has elapsed. The default dead time is 3 seconds).
5. To exit at any time press **MENU** button firmly.

NOTE: If no voice activation has been detected after 3 minutes, voice mode will deactivate.

Using remote in auto mode with voice activation


1. Ensure voice activation is on, then press and hold the **MENU** button.
2. Press 'Auto' button (**4-D**) and the 'Auto' LED will illuminate.
3. Release the **MENU** button and press a program number between 1 and 6. The 'Auto' LED and 'DT' LED will be on solid for 3 seconds.
4. After 3 seconds, the 'DT' LED will turn off and 'Auto' LED will flash. The system is now ready.
5. Call "PULL" to activate.

NOTE: The 'TX' LED light will be on solid at the start of each program cycle and will flash in between cycles.

Using remote in auto mode without voice activation

1. Ensure voice activation is off, then press and hold the **MENU** button.
2. Press 'Auto' button (**4-D**) and the 'Auto' LED will illuminate.
3. Release the **MENU** button and press a program number between 1 and 6. The 'Auto' LED and 'DT' LED will be on solid for 3 seconds.
4. After 3 seconds, the 'DT' LED will turn off and 'Auto' LED will flash. The system is now ready.
5. Use the **TP** button to activate.

NOTE: The 'TX' LED light will be on solid at the start of each program cycle and will flash in between cycles.



e-Trap 10 Button Voice Command Remote





Coding remote

1. Press and hold **CODE** button until blue 'Code' LED comes on, then release **CODE** button.
2. Press the button on the remote that you want to activate the Transceiver, the blue 'Code' LED will flash. Release button.
3. Press remote button again and 'Code' LED will flash a second time to confirm. Remote is now coded.
4. You can follow up with a second remote, or if you press remote button for a third time all LEDs will flash and code learn will be exited.
Code learn will exit after 5 seconds if no remotes are detected.

NOTE: 1. This can only be done when voice activation is not enabled.

2. If the Transceiver's button allocation had been set to number 1, even if you coded button 8 on remote, the Transceiver will only accept button 1. Refer to Clay Trap Transceiver instructions to change.




10 BUTTON REMOTE




Menu options

Channels 8 button plus one two pair (TP) is set as standard.



To convert remote to 7 button and 2 x two pair (TP)

1. Press and hold the **MENU** button, then press and hold the **7-G** button for 5 seconds until the 'TP' LED comes on.  Now release the **MENU** button.
2. The remote is now set for 7 button and 2 x two pair operation. The **7-G** button is now the second two pair button.
3. To change back, follow the same procedure.




To set the buttons the TP button will activate


1. Press and hold the **MENU** button. 'Menu' LED will illuminate. 
2. Now press and release the **TP** button while keeping your finger held on the **MENU** button. The 'TP' LED will illuminate. 
3. Press the first button number that you want the **TP** button to activate, and the 'TP' LED will flash once. 
4. Press the second button number, and the 'TP' LED will flash twice. Release the **MENU** button and the TP button allocation has now been set.

To change TP activation from true pair to report pair



1. Press and hold the **MENU** button then press **5-E** button and the 'TP' LED will activate. This indicates 'true pair'. 
2. Press the **TP** button the 'TP' LED will now continuously flash which indicates 'report pair'. Now release the **MENU** button. 
3. To change back, follow the same procedure.

To set the buttons the 7-G button will activate




1. Press and hold the **MENU** button. 'Menu' LED will illuminate. 
2. Now press and release the **7-G** button while keeping your finger held on the **MENU** button. The 'TP' LED will illuminate. 
3. Press the first button number that you want the **7-G** button to activate, and 'TP' LED will flash once, then press the second button number and 'TP' LED will flash twice. 
4. Release **MENU** button and the **7-G** button allocation has now been set.



To activate voice mode




1. Press and hold the **MENU** button. 
2. Press 'Voice Enable' button (**1-A**) and the 'Voice' LED will activate. 
3. Now remove finger from **MENU** button. Voice activation has now been enabled.
4. To turn off voice activation, follow the same procedure to turn off the 'Voice' LED.

To change voice sensitivity settings





1. Press and hold **MENU** button. 
2. Press 'Voice Sensitivity' (**2-B**). The voice sensitivity will show by the amount of LEDs illuminated (1 LED means low sensitivity and 6 LEDs means high sensitivity). 
3. To change settings, press a number between 1 and 6 and your new setting will now show. This example is for highest voice sensitivity setting. 
4. Now remove finger from **MENU** button.

To set dead time (DT)

Dead Time (DT) is how long the voice stays deactivated after a trigger. The standard time is 3 seconds, but this can be changed from 1 to 6 seconds.

1. Press and hold **MENU** button, then press 'Dead Time' (**3-C**). 
2. The time will show by the amount of LEDs illuminated. (1 LED means 1 second and 6 LEDs means 6 seconds). 
3. To change settings, press a number from 1 to 6 and your new setting will now show. This example is for 6 seconds. 
4. Now remove finger from **MENU** button.

To set auto mode program sequence

1. Press and hold **MENU** button. 
2. Press 'Auto' button (**4-D**) and the 'Auto' LED will illuminate. 
3. Now press a program button between 1 and 6. The 'Auto' LED will now flash. 
4. Enter firing sequence, for example **1, 4, 3, 8, TP**. The 'TX' led will flash each time a button is pressed. 
5. Now release the **MENU** button and the program has been stored.

NOTE: Auto sequence is turned off when exiting. To add more programs, follow the same sequence. Up to 6 programs can be stored.

